



## Model AF353 Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	HY00000530	HEX. SOCKET HEAD BOLT M4X20	4	
002	HY00000070	WASHER	4	PC.
003	HY00000544	TOP CAP	1	
004	HY00000578	TOP CAP GASCKET	1	
005	HY00000581	CUSHION V	1	
006	HY00000594	HEAD VALVE GUIDE	1	
007	HY00000417	O RING 25	2	
008	HY00000626	COMPRESSION SPRING 5	1	
009	HY00000010	O-RING 12	1	PC.
010	HY00000593	HEAD VALVE	1	
011	HY00000417	O RING 25	2	
012	HY00000406	O RING 19	1	
013	HY00000415	O RING 8.5	1	
014	HY00000555	CYLINDER SEPARATER	1	
015	HY00000418	O RING 32.5	1	
016-1	HY00000416	O RING 23.5	1	
017-1	HY00000549	DRIVER BLADE ASSEMBLY	1	
018	HY00000413	O RING 15.5	1	
019	HY00000600	CYLINDER	1	
020	HY00000547	FRONT BUMPER	1	
021	HY00000484	FRON TSEAL	1	
022	HY00000640	HOUSING ASSEMBLY	1	
	D10	INC. 23-27		
023	HY00000586	AF353 NAME PLATE	1	
024	HY00000556	GRIP	1	
025	HY00000105	CAUTION LABEL	1	PC.
026	HY00000425	HOUSING BUMPER R	1	
027	HY00000424	HOUSING BUMPER L	1	
028	HY00000062	HOOK	1	PC.
029	HY00000075	HEX. SOCKET HEAD BOLT M5X30	1	PC.
030	HY00000064	STOP RING (EXT) E-2.5	1	PC.
031	HY00000435	LOCK LEVER	1	
032	HY00000617	TORSION SPRING 3	1	
033	HY00000638	PIN 3	1	
034	HY00000682	SPRING PIN 3-25	2	
035	HY00000411	O RING 2	1	
036	HY00000434	TRIGGER	1	
037	HY00000595	PIN 3	1	
038	HY00000411	O RING 2	1	
039	HY00000420	O RING	1	
040	HY00000598	TRIGGER VALVE GUIDE	1	
041	HY00000419	O RING	1	
042	HY00000548	COMPRESSION SPRING 4	1	
043	HY00000037	O-RING 3	2	PC.
044	HY00000516	TRIGGER VALVE STEM	1	
045	HY00000010	O-RING 12	1	PC.
046	HY00000597	TRIGGER VALVE CASE	1	
047	HY00000040	COMPRESSION SPRING 10	1	PC.
048	HY00000438	LINK	1	

049	HY00000604	DRIVER GUIDE	1
050	HY00000681	HEX. SOCKET HEAD BOLT M4X14	2
051	HY00000680	SPRING PIN 2.5-10	2
052	HY00000681	HEX. SOCKET HEAD BOLT M4X14	1
053	HY00000534	DRIVER GUIDE COVER	1
054	HY00000071	HEX. SOCKET HEAD BOLT M4X6	2 PC.
055	HY00000561	NOSE NO MAR TIP	1
056	HY00000568	PIPE ASSEMBLY	1
	D10	INC. 57-59	
057	HY00000398	O RING 6.5	1
058	HY00000572	PIPE	1
059	HY00000398	O RING 6.5	1
060	HY00000579	SEAL RING	1
061	HY00000496	AIR DUSTER ASSEMBLY	1
	D10	INC. 62-72	
062	HY00000573	DUSTER BUTTON	1
063	HY00000046	PIN 2	1 PC.
064	HY00000414	O RING 10.5	1
065	HY00000591	COMPRESSION SPRING 5	1
066	HY00000513	VALVE STEM	1
067	HY00000037	O-RING 3	2 PC.
068	HY00000399	O RING 8.5	1
069	HY00000599	VALVE GUIDE	1
070	HY00000397	O RING 5	1
071	HY00000497	INLET CAP	1
072	HY00000054	SPRING PIN 2.5-18	1 PC.
073	HY00000001	HEX. SOCKET HEAD BOLT M4X10	4 PC.
074	HY00000431	INLET CAP COVER	1
075	HY00000532	FLAT WASHER 4	2
076	HY00000647	HEX. SOCKET HEAD BOLT M4X12	2
077	HY00000079	ONE TOUCH JOINT	1 PC.
078	HY00000073	HEX .LOCK NUT M5	1 PC.
079	HY00000542	JOINT	1
080	HY00000681	HEX. SOCKET HEAD BOLT M4X14	2
081	HY00000474	MAGAZINE ASSEMBLY	1
	D10	INC. 82-112	
082	HY00000574	CASE	1
083	HY00000576	DOUBLE SIDED TAPE	1
084	HY00000071	HEX. SOCKET HEAD BOLT M4X6	1 PC.
085	HY00000662	CAUTION LABEL	1
086	HY00000683	HEX. SOCKET HEAD BOLT M3X10	2
087	HY00000680	SPRING PIN 2.5-10	1
088	HY00000483	MAGAZINE	1
089	HY00000620	SPACER	1
090	HY00000485	LOWER RAIL	1
091	HY00000571	STOPPER	1
092	HY00000445	COMPRESSION SPRING 3	1
093	HY00000489	PUSHER	1
094	HY00000492	PIN 5	1
095	HY00000684	SPRING PIN 2.5-8	1
096	HY00000478	SLIDE DOOR	1
097	HY00000660	CAUTION LABEL	1
098	HY00000614	COMPRESSION SPRING 4	1
099	HY00000623	NAIL STOPPER	4
100	HY00000619	LEAF SPRING	1
101	HY00000622	NAIL GUIDE HOLDER	1

102	HY00000615	COMPRESSION SPRING 4	1
103	HY00000613	COMPRESSION SPRING 3	4
104	HY00000646	HEX. NUT M4	1
105	HY00000501	SLIDE DOOR CAP	1
106	HY00000561	NOSE NO MAR TIP	1
107	HY00000612	COMPRESSION SPRING 6	1
108	HY00000504	LEVER	1
109	HY00000685	SPRING PIN 3-18	1
110	HY00000532	FLAT WASHER 4	1
111	HY00000161	SPRING WASHER 4	1 PC.
112	HY00000001	HEX. SOCKET HEAD BOLT M4X10	1 PC.
	181434-7	OIL SUPPLY	
	191687-A	SAFETY GOGGLES	
		TOOL CASE	
		HEX. WRENCH	